



INSTALLATION INSTRUCTIONS

4388 N. Carson St., Carson City, NV | Customer Support: 805.988.2900 | Fax: 805.988.2946 | www.gbrakes.com

YEAR: 2002-09	MAKE: HONDA	MODEL: CB 900F(919) Hornet
PRODUCT # FK003D310R	PRODUCT DESCRIPTION:	Rear Brake Line Kit
LIFETIME WARRANTY		

Torque specifications

Stainless steel 15-17 ft. lbs

Aluminum 12-15 ft. lbs

Step 1:

Identify the key components that complete our brake line kit:

You should have one (1) line, two (2) single banjo bolts. We have also included a total of six (6) washers; four (4) will be used, and two (2) will be spares. We strongly suggest having a professional mechanic install your brake lines, all other installs may void your warranty.

Step 2:

To ensure there is no paint damage from the brake fluid, completely cover the rear end of the bike. Installing brake lines can be a messy process, and brake fluid WILL spill!

Step 3:

After bleeding and drying out the OEM brake system, uninstall your rear stock hose. Take note of how the stock system was routed in case you need to re-install the hose.

Step 4:

Identify which fitting to install at the master cylinder. Install this end using a single banjo bolt and two (2) washers, the sequence should be as follows; master cylinder, washer, banjo fitting, washer, single banjo bolt (refer to pictures A and B.) Be sure to note what type of fittings you have received, since torque specs will vary.

Step 5:

Route the GBrakes line through your OEM routing tabs, to help keep the line in place (refer to pictures A and B.) Install the line at your caliper using a single banjo bolt and two (2) washers, using the same sequence as the master cylinder (refer to picture C.)

Step 6:

Before you begin the next step, please check the clearance of your new lines. When the rear end is fully extended or compressed, make sure the lines do not bind with anything. Be sure to triple check that the lines are traveling correctly and are clear from any obstructions.

Step 7:

Bleed your brake system according to the owner's manual. Add DOT-4 brake fluid to the system and build appropriate pressure.



Step 8:

Once you have bled the system, please check the brake fluid level in your master cylinder. Top off your brake fluid according to your manual and close the brake fluid reservoir. To ensure there are no leaks or other issues, use a jug or something similar to apply pressure to your brake pedal for at least 2 hours. If the lines are not leaking and all else looks good, (bolts are tight and torqued down to specification, washers are in place, and lines are clear from obstruction) you are now ready to ride with the new brake system.

Please be aware that the overall braking feel has been changed dramatically. We suggest taking it easy while you get used to the new brake lever pressure and feel. We recommend checking your brake system periodically; be sure to check that your bolts are tight and VERY carefully check your lines for any leaks or damage. If there are any signs of damage or stress to the lines, the complete brake line kit will need to be replaced. Remember, our brake lines have a LIFETIME WARRANTY! If you have any problems or questions, do not hesitate to call our tech department - (805)988-2900



a. Rear master cylinder, notice positioning of banjo



b. Rear line overall, using OEM tabs for routing purposes



c. Rear caliper